




## KL-1280-7047

Socket Spanner 8-edge for Turbocharger Exhaust Housing



### Product information

 Read and understand before use!

EN



[www.gedore-automotive.com](http://www.gedore-automotive.com)



#### GEDORE Automotive GmbH

Breslauer Straße 41  
78166 - Donaueschingen  
Postfach 1329  
78154 Donaueschingen - GERMANY

☎ +49 (0) 771 / 8 32 23-0  
☎ +49 (0) 771 / 8 32 23-90  
✉ info.gam@gedore.com  
🌐 gedore-automotive.com

#### GEDORE TOOLS, INC.

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México  
Seulement pour les USA, le Canada et le Mexique  
7187 Bryhawke Circle, Suite 700  
North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15  
☎ +1-843 / 225 50 20  
✉ info@gedoretools.com  
🌐 gedore.com

## Product description

### KL-1280-7047 - Socket spanner 8-edge for turbocharger exhaust housing

Suitable for 8-edge special profile bolts on Renault, Fiat, Mercedes-Benz, Nissan, and Vauxhall/Opel 1.6 (R9M) diesel engines. Installed on Renault Megane III, Talisman, Scenic III, Espace V, Grand Scenic, Trafic III; Fiat Talento; Mercedes-Benz C180 (205), C200 (205), Vito (447); Nissan Qashqai (J10/J11), X-Trail (T32), NV300; Vauxhall/OPEL Vivaro-B etc.

Also suitable for 8-edge special profile bolts on the bonnet of Renault Master, Traffic; Nissan Primastar Turbo; Vauxhall/Opel Movano etc.

Required for loosening and tightening the 8-edge special profile bolts on the charge air pipe (exhaust housing) after the turbocharger\*, or on the engine hood. \*Not required for bi-turbo engines!

EN



### Scope of supply/component overview

Item	Part no.	Description	Qty.
-	KL-1280-7047	Socket spanner 8-edge for turbocharger exhaust housing	1

### Specifications

Special profile: ..... 8-edge

Size: ..... 10 mm

Length: ..... 50 mm

Drive: ..... 1/4"



### ⚠ Safety instructions and regulations

- **Prior to each use** of the special tools, read and understand all safety instructions and **follow** them for **safe use**!
- Use the special tools **as intended** and **always** carry out maintenance and repair work in compliance with the regulations on occupational safety and accident prevention as well as the vehicle manufacturer's instructions!
- **Prior to each use**, check the special tools **carefully** for damage, loose parts or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- **Always** wear your personal protective equipment (for example safety goggles, protective gloves, safety shoes) when working!